

**TECHNICAL RECOMMENDATIONS**

**1** 1. PROTECT THE SHEETS BY THE SUN AND RAIN

**2** 2. EASYPIU' SHEET IS UV PROTECTED ON BOTH SIDES

**3** **NO** 3. MULTIWALL POLYCARBONATE SHEETS CAN NOT BE WALKED UPON

**4** **NO** 4. DO NOT WALK ONTO THE SHEETS AT ANY TIME. FOLLOW SAFETY REGULATIONS AND SAFE METHODS OF INSTALLATION

POLYCARBONATE SUFFER THE CHEMICAL ATTACK OF SOME PRODUCTS THEREFORE;

**5** 5. USE ONLY COMPATIBLE CLEAR SILICONE FOR THE SEALING

**6** 6. USE ONLY WATER AND MILD DETERGENTS FOR THE CLEANING

**7** 7. CUTTING OF THE SHEETS CAN BE EXECUTED ON SITE BY MEANS OF A HACK SAWING MACHINE (1) OR OF A CUTTER (2). SEAL THE OPEN CELLS AFTER THE CUTTING

**8** 8. TAKE OFF THE PROTECTIVE FILM BEFORE THE INSTALLATION

**9** 9. SEAL THE OPEN CELLS WITH AN ADHESIVE ALUMINIUM TAPE

**10** 10. PROTECT THE SEALING WITH AN UPPER AND A LOWER PROFILE

**10.a** 10.a LOWER PROFILES MUST BE DRILLED FOR WATER DRAINING

**11** 11. DRILLING OF THE SHEETS CAN BE EXECUTED ON SITE BY MEANS OF A DRILL AND SUITABLE HEADS. THE HOLE MUST BE 3mm WIDER THAN SCREW GAUGE OR A SLOT ALONG THE LENGTH

**12** 12. CHECK OUR TECHNICAL LITERATURE TO DETERMINE LOADING AND SPACING OF THE WHOLE SYSTEM

